


Pracovní listy pro sestavení robota

Manipulační rameno




Postup sestavení robota:


Krok 1

F3 x 1

S1 x 4





Krok 2




Krok 3

- F3 x 1
- F4 x 1
- F10 x 1
- S3 x 4
- N1 x 4




Krok 4




Krok 5


S1 x 8 N1 x 8 BU x 1 WA x 1 S-B x 1




Krok 6

S1 x 4





Krok 8



Krok 9

F4 x 2



S1 x 8

N 1 x 8

BU x 2


WA x 2

S-B x 2




Krok 10

S1 x 8



Krok 11

F3 x 2 F52 x 1 S1 x 8 N1 x 8



Krok 12

F3

x 1

F51



x 1

S1

x 4




N1

x 4




Krok 13

F3 x 1 F10 x 2 F60 x 1 S5 x 4 N1 x 4



Krok 14





Krok 15

S1 x 16


CM-510 x 1

Krok 10

Krok 14



Krok 16



Krok 17

BATERIE

x 1

